



# Heavy Guardrail Quick & Easy Installation

(Templates available upon request)

## Bolt In

Works for all heights

1. Mark out guardrail placement on concrete and align rails with base plates (templates available upon request)
2. Using a 3/4" core bit, drill holes in surface with hammer drill
3. Secure base plate with 3/4" by 6 1/4" anchors
4. Guardrail is now installed



## Core In

27" height and lower

1. Using a 5 1/8" core bit, core holes into depth of concrete
2. Using a forklift or two person team, place guard rail above cored holes (legs will be loose when picked up but will secure in place once installed)
3. Guide legs into cores
4. Guardrail is now installed



## Core In

27" height and higher

1. Using a 10" core bit, core hole at least 12" into concrete
2. Drop in 5x5 square steel floor sleeve and fill in corners with cement
3. Guide legs into steel floor sleeve
4. Guardrail is now installed

