



# Standard Guardrail Quick & Easy Installation

(Templates available upon request)

## Bolt In

Works for all heights

1. Mark out guardrail placement on concrete and align rails with base plates (templates available upon request)
2. Using a 3/4" core bit, drill holes in surface with hammer drill
3. Secure base plate with 3/4" by 6 1/4" anchors
4. Guardrail is now installed



## Core In

27" height and lower

1. Using a 2 7/8" core bit, core hole into depth of concrete
2. Using a forklift or two person team, place guard rail above cored holes (legs will be loose when picked up but will secure in place once installed)
3. Guide legs into cores
4. Guardrail is now installed



## Core In

27" height and higher

1. Using a 5 1/8" core bit, core hole at least 12" into cement
2. Drop in 3" round steel tube into cores
3. Guide legs into steel tubes
4. Guardrail is now installed

