



Decorative Bollard Cover Installation

Fast. Easy. Secure Installation.



1. 6" Decorative Bollard Cover with 6" – 5/8" O.D. steel pipe.
2. Remove the back of the first adhesive tape strip and wrap it firmly around the post, approximately 6" from the top. There should be a 1" gap between the ends of the tape to allow air to pass through when you install the bollard cover. Remove the back of the second piece of neoprene adhesive tape strip and wrap it firmly around the bottom of the post, securing the ends of the tape together.
3. Simply lift decorative bollard cover and slowly slide the Ideal Shield bollard cover over the post. If the tape is applied correctly, you will hear air being forced out.
4. The decorative bollard cover should fit entirely over the length of the post. You now have a durable, maintenance-free, securely fit decorative bollard cover and an instantly enhanced facility appearance!