

FLEXPOST-XL™ ANCHORING INSTRUCTIONS FOR ASPHALT

Tools Required:

- Rubber Mallet
- Wax Pencil / Marker
- 1/2" Masonry Drill Bit
- 3/4" Ratchet

Parts Included:

- 1 Base Plate
- 4 Mungo Plugs
- 4 Hex Lag Screws
- 4 Flat Washers
- (1) 3/16" Allen Key

**WARNING: MUST ANCHOR UNIT ON THE SAME LEVEL AS THE
PARKING LOT FOR PROPER FUNCTIONALITY**



- Place base plate in desired anchoring location
- Mark the four base holes with a wax pencil



- Using a 3/4" masonry bit, drill 6" in depth



- Use a rubber mallet or hammer to stuff mungo plugs into the drilled holes



- Make sure the top of each mungo plug is flush with the asphalt surface



- Place the base plate over the four holes and use a socket wrench with a 15/16" drive to thread all four hex lag screws



- Insert post over spring, tighten both set screws with a 3/16" allen key (provided)



2525 Clark St.

Detroit, MI 48209

1-866-825-8659 • www.idealshield.com