



# OCTAGON SIGN BASE INSTALLATION INSTRUCTIONS

**Tools Needed: Two 3/16" Allen Wrench**

**Step #1:** Insert the sign pole, making sure that it's in line with the base's interior nub.

**Step #2:** Using two, 3/16" Allen Wrenches (not included), insert screw in the designated hole at the top of the base.

**Step #3:** Move to designated location **before** filling.

**Step #4:** Remove cap from top of Sign Base and fill with chosen filler based on your stability needs. **\*Sign size and filler option affects tip point.**

**4a.** Pea Gravel: make sure signpost is installed before filling, use large funnel for easier install.

**4b.** Sand: make sure signpost is installed before filling, use large funnel for easier install.

**4c.** Concrete: make sure signpost is installed before filling, use large funnel for easier install.

**Step #5:** Once filled, replace cap on top of the sign base.



**Visit the Ideal Shield Youtube  
Channel for video installation**

**Ph: (866) 825-8659  
Fax: (313) 842-7860  
www.idealshield.com  
Email: info@idealshield.com  
2525 Clark St - Detroit, MI 48209**