Heavy Duty Guardrail

Core-In with Cement Installation

Available for All Heights

1. Layout Guardrail in appropriate location on concrete
2. Mark centerline of post on floor
3. Using a 12” core bit (or larger); core 12” deep or greater
4. Using a forklift or two-person team, align Guardrail above holes (Guardrail legs will be loose but become secure once installed)
5. Cement Guardrail legs into place
6. Once concrete dries, your Guardrail is now installed