Heavy Duty Guardrail

Core-In with Steel Floor Sleeve Installation

Available for 28” Height or Taller

1. Layout Guardrail in appropriate location
2. Mark centerline of post on floor
3. Using a 12” core bit (or larger); core 12” deep or greater
4. Cement 5” x 5” square steel floor sleeve tube into cored hole (tube sold separately)
5. Using a forklift or two-person team, align guardrail above holes (Guardrail legs will be loose but become secure once installed)
6. Guide Guardrail legs into 5” x 5” round steel floor sleeve tube
7. You Guardrail is now installed and removable when necessary