



Standard Guardrail

Core-In with Cement Installation

Available for All Heights

- 1. Layout Guardrail in appropriate location on concrete**
- 2. Mark centerline of post on floor**
- 3. Using a 10” core bit (or larger); core 12” deep or greater**
- 4. Using a forklift or two-person team, align Guardrail above holes
(Guardrail legs will be loose but become secure once installed)**
- 5. Cement Guardrail legs into place**
- 6. Once concrete dries, your Guardrail is now installed**