



## **Standard Guardrail**

# **Bolt-In Base Plate Installation**

### **Available for All Heights**

- 1. Layout Guardrail in appropriate location on concrete**
- 2. Using a 3/4" drill-bit; drill holes with a hammer drill**
- 3. Secure base plates with [4] 3/4" x 6 1/4" anchors\***
- 4. Your Guardrail is now installed**

**\*epoxy anchors can be used as well**

