



Standard Guardrail

Core-In with Steel Floor Sleeve

Available for 28” Height or Taller

- 1. Layout Guardrail in appropriate location**
- 2. Mark centerline of post on floor**
- 3. Using a 10” core bit (or larger); core 12” deep or greater**
- 4. Cement 3” round steel floor sleeve tube into cored hole
(tube sold separately)**
- 5. Using a forklift or two-person team, align guardrail above holes
(Guardrail legs will be loose but become secure once installed)**
- 6. Guide Guardrail legs into 3” round steel floor sleeve tube**
- 7. You Guardrail is now installed and removable when necessary**