



Bollard Cover Sizing Tool

Cut out strips to place across the top of pipe to get a correct measurement.

*Bollard cover sizes are Ideal Shield Specific

This is the outside of your pipe

This is the inside of your pipe

Measure outside to outside
This pipe will need a 3" bollard cover

3.5" OD = 3" Bollard Cover

4" OD = 3.5" Bollard Cover

4.5" OD = 4" Bollard Cover

5.563" OD = 5" Bollard Cover

6.625" OD = 6" Bollard Cover

7.5" OD = 7" Bollard Cover

8.625" OD = 8" Bollard Cover

Anything beyond 8" will need a 10" Bollard Cover