

Removable Locking Bollard Installation Instructions (Pre-Concrete)



Step #1

Auger or dig out 10-12" hole to depth of core (generally 18")



Step #2

Level plum and concrete around receiving steel floor sleeve



Step #3

After concrete cures, make sure the floor sleeve is secure before dropping in Removable Locking Bollard

THANK YOU FOR YOUR ORDER!

LET US KNOW ABOUT YOUR ORDER EXPERIENCE
AND PRODUCT SATISFICATION ON 



(866) 825-8659
WWW.IDEALSHIELD.COM
2525 CLARK ST - DETROIT, MI 48209



Providing maintenance free protective products for all your facility needs

Featured Products:

Bollard Covers, Sign Bases, Goal Posts, and Handrail



Facility protection by Ideal Shield provides maintenance free, easy to install, heavy duty solutions for any type of facility.

See reverse side for instructions



(866) 825-8659
WWW.IDEALSHIELD.COM
2525 CLARK ST - DETROIT, MI 48209