# HEAVY DUTY ASPHALT ANCHORING

PART #RE-HDAA

**IMPORTANT: WEAR SAFETY GLASSES • CHECK UNDERGROUND FACILITIES**

**Tools Required:** • Mallet / Hammer • Wax Pencil / Marker • Tape Measure • 7/8” Masonry Drill Bit • 9/16” Ratchet • Measuring Cup • 3/8 Cup of Water • 3/16" Allen Key

**Parts Included:**
• 1 XL Unit
• 4 HD Anchors, Washers, 9/16 Bolts
• 2 Bags of Grout

**DO NOT PLACE WITHIN 10” OF ANY CURB**

**MARK 4 HOLES**

**MARK YOUR DRILL BIT AT 6”**

**DRILL 4 HOLES 7/8” DIAMETER 6” DEEP**

**CLEAR AWAY ANY DUST OR DEBRIS**

**MEASURE 3/8 CUP WATER**

**GATHER ALL MATERIALS PRIOR TO MIXING GROUT!**

**SLOWLY MIX APX. 3/8 CUP WATER WITH GROUT MIXTURE**
**(DON’T DUMP ALL THE WATER, ADD JUST A LITTLE AT A TIME)**

**KNEAD TO SYRUP CONSISTENCY**
**(ONLY MIX ONE BAG AT A TIME!)**

**POUR MIXTURE INTO THE 4 HOLES (ONE BAG PER TWO HOLES)**

**USING A RUBBER MALLET, TAP BOLTS INTO THE HOLES**

**WITH A DAMP CLOTH, WIPE AWAY ANY EXCESS**

**USING A 9/16” RATCHET, TIGHTEN BOLTS**

(866) 825-8659
WWW.IDEALSHIELD.COM