



CURBIE Parking Curb Installation Guide

Components:


- CURBIE Parking Curb
- Lag bolts with metal shields or 1/2" rebar spikes

What you will need:

- PPE (gloves, safety glasses, pylons/signage to secure work site)
- Mallet
- Heavy Duty Electric Drill
- 1/2" masonry bit
- A drive socket and a power tool for installation of the lag bolts
- *If installed using lag bolts, Use a masonry bit for the metal shields.

Curbie Installation Instructions using Lag bolts and Shields.

(Recommended for installation into concrete surfaces):

STEP 1:	Use 1/2" or 5/8 lag bolts(6" long) Drill 1/2" diameter pilot holes (3-4" in depth) through the products installation holes. 
STEP 2:	Remove the curbie: re-drill the holes for the diameter and depth required by the metal shields.
STEP 3:	Install the metal shields, re-position the Curbie and bolt with lag bolts.

Curbie Installation Instructions using Rebar Spikes

(Recommended for installation into asphalt surfaces):

STEP 1:	Drill 1/2" diameter holes(3-4" in depth) in the asphalt in the desired location through the curbie's holes on the top of the product.
STEP 2:	Drive 1/2" rebar spike(12" long) through the holes in the Curbie. 